# ADDENDUM
# Digital Recorder
## with Variable Playback Speed Control

## 14-1191

If you do not plan to use the recorder for a week or more, please remove the batteries. Even when not in use, the recorder uses a small amount of current.

© 2001 RadioShack Corporation.
All Rights Reserved.
RadioShack and RadioShack.com are trademarks used by RadioShack Corporation.

06A02 Printed in Korea